


Sno-Konette Machine Instructions

NEEDED FOR UNIT USE:

15 AMP DEDICATED LINE



Requirements: 15 amp Receptacle
Ice Cubes
Snow Cone Cups
Liquid Flavoring
Liquid Flavoring Pumps
Bucket for melting ice

SNOW CONE MACHINE

3 OR 4 BLOCKS OF ICE & 1 GALLON
OF SYRUP = APPROX. 100 - 6oz CUPS.

Instructions:

1. Place "Drain Sheet Pan" on flat surface with drain tube into a bucket.
2. Place Sno-Konette machine onto pan.
3. Plug unit in.
4. Turn "Light switch" on.
5. Push "Motor Switch" on and wait for motor to reach optimum speed.
6. Fill the gooseneck to within an inch of the top with ice cubes or block ice (no larger than 3" to 4"). The larger the pieces, the better the snow.
7. Push the handle down against the ice in the gooseneck. Apply firm and even pressure to make the best snow. Practice will allow you to gauge when to stop pressing. This allows the ice to resettle against the cutter head. You may find that you need to relieve the pressure two or three times in a cycle. Over pressing will stall the motor. In this case, simply relieve the pressure and try again. Too much pressure will result in snow that is course; too little pressure will make the snow mushy.
8. Serve snow in the cups using the scoop that is provided.
9. Squirt desired flavoring onto snow. Never add flavoring to snow within the machine.

Cleaning:

1. Make sure machine is free of ice and water.
2. Place hand pumps in warm water and pump until water comes out.
3. Return pumps that are fully functional to receive deposit back.

Rhode Island Rentals

401-738-9731