

RHODE ISLAND RENTALS

111 PLAN WAY
WARWICK RI 02886
(401) 738-9731

NEEDED FOR UNIT USE:

15 AMP DEDICATED LINE

NACHO MACHINE INSTRUCTIONS

Requirements: 15 AMP receptacle

#10 CAN OF NACHO CHEESE

(1-10 oz CAN = APPROXIMATELY 53 – 2 oz SERVINGS)

NACHO CHIPS

- **CHEESE MUST BE PRE-HEATED BEFORE INSERTING CAN INTO MACHINE. PUMP WILL NOT FUNCTION PROPERLY IF CHEESE IS COLD.**

OPERATING INSTRUCTIONS:

1. PLACE METAL WATER RING INTO CHEESE HOLDER.
2. FILL CHEESE HOLDER W/HOT WATER TO THE TOP OF THE RING.
NEVER PUT CAN OF CHEESE INTO HOLDER WITHOUT WATER.
BURNING WILL OCCUR RESULTING IN ADDITIONAL **CLEANING CHARGES.**
3. PLACE #10 CAN OF **PRE-HEATED** CHEESE INTO HOLDER.
4. PLUG IN UNIT.
5. TURN ON POWER SWITCH.
6. TURN DIAL TO THE HIGHEST SETTING TO WARM UP UNIT.
7. PLACE CHIPS IN UNIT TO WARM.
8. AFTER UNIT IS HEATED, TURN DIAL TO DESIRED SETTING.

CLEANING INSTRUCTIONS:

1. PLACE PUMP INTO HOT WATER AND PUMP UNTIL WATER RUNS CLEAR.
2. REMOVE ALL CHIPS & CRUMBS FROM UNIT.

***NEVER DISASSEMBLE PUMP!**