

## Chuppah Instruction Sheet



Lay out the four poles and four corner castings.



Connect the four poles and corners by pushing in the push pins into the holes on the corner castings.



This is how it will look after the four corners are assembled.



Place the two braces across in either direction onto the eave bars.



Place the top on, making sure to match the Velcro to the Velcro on the side of the eave bars.



Place two legs on one side making sure the push pins lock into the corner casting on the bottom hole.



Place the remaining legs on the corner castings.



**Optional:** Fold back the top to make attachment easier. Leg drapes should be folded in half to find the center. Place the center of the drape's Velcro onto the top of the corner casting Velcro. Run the drape along the top Velcro 12", then return toward the back of the chuppah attaching to the Velcro for the top. Attach the last two clips into the hole in the corner casting as shown. The drapes can also be run out to close off sides if desired.



Place the top over the leg.



Use the tie backs if desired.



Here is the finished chuppah with the back closed off with the two rear leg drapes.