


# RHODE ISLAND RENTALS

401-738-9731

## Bubble Machine



### Operation

This bubble machine has been designed to function on a mains power supply of either 120V~60Hz or 230V~50Hz and has been fitted with a suitable power plug for use with your local voltage. Check the label on the unit and the power plug for the correct voltage.

Place the machine on a level surface and loosen the thumbscrew on the front of the unit for fluid tank access, see diagram (fig.1). This will allow the whole of the top cover to be lifted revealing the fluid tank in the base. Fill the tank with quality bubble fluid only. We recommend use of CHAUVET bubble fluid (BJ-U or BJ-Q) as it has been specially formulated for use with CHAUVET bubble machines and produces the best results. Replace the cover and tighten screws. Plug into the mains power supply and stand back in amazement as you fill the area with hundreds of bubbles!

*After use, ensure that all bubble fluid is drained before moving.*

### Cleaning

Cleaning your bubble machine regularly will help reduce costly parts replacement and repair charges.

After every 40 hours of continuous operation or when the machine will be idle for a long time it is recommended to rinse the bubble wands and fluid tank with warm water, to prevent a build-up of residue which could reduce performance.

1. While the unit is unplugged, loosen thumbscrew and lift cover to reveal fluid tank.
2. Empty all bubble fluid from the tank and replace with warm water. Plug unit in and allow to run as usual, until all wands appear to be free of residue.
3. Cleaning is now complete. Unplug and refill with bubble fluid.

All bubble machines are prone to clogging due to the consistency of bubble fluid. However a well maintained machine should provide years of reliable use. The body of the unit may be cleaned with a soft damp cloth. Store dry.

### Caution

Do not obstruct the bubble wands. Never allow children to place fingers inside the front of the machine. Do not leave machine unattended.

Danger of Slipping. Bubble fluid produces a slippery residue. Do not leave machine unattended.

Always disconnect from main power supply before cleaning or servicing.

Never use any other type of liquid other than quality bubble fluid. CHAUVET provide suitable fluids for use with this machine (BJ-U or BJ-Q).

Never drink bubble fluid. If its ingested, call a doctor immediately. If bubble fluid comes into contact with eyes, rinse thoroughly with water.

Beware of overfilling or spillage. Consider carefully when mounting.

No user serviceable parts inside, please refer to CHAUVET for service.